

## **UTG GEN III Blank Firing Adaptor**

### **Note:**

- Blank firing adaptor for Model 4 rifles is RED.
- Blank firing adaptor for Model 4 carbines is YELLOW.
- Every 50 rounds, check to make sure that the adaptor is still tight and secure. Clean up carbon build-up after each use.



Before installation, be sure to clear the weapon.

Don not use tools to tighten adaptor.  
**HANDS TIGHTEN ONLY.**

Website: [www.leapers.com](http://www.leapers.com)

Telephone: 734-542-1500

E-mail: [office@leapers.com](mailto:office@leapers.com)

## **UTG GEN III Blank Firing Adaptor**

1. Unscrew the bolt and slide it all the way out.



2. Hook the adaptor into the first groove of the compensator.



3. Slide the bolt into the compensator and **HAND TIGHTEN**. Do not use any tool.

